Mortise Chisel Adapter

Accommodates mortise chisels up to 11/16" thick.





- as shown. Note the direction of the central boss and the Veritas logo. (Discard nut.)
- 1. Orient the adapter on the roller base 2. Attach the narrow-blade carrier to the adapter using the included longer brass thumbscrew.

Use the assembled guide to hone a mortise chisel as you would any other blade. The registration jig will yield the correct bevel angle within the 30° to 35° range typical of mortise chisels. Outside this range, the resulting bevel angle will be 1° to 1.5° off what is set by the registration jig, as shown in the table.

Registration Jig Setting	Actual Angle
15°	16.5°
20°	21.4°
25°	26.2°
30°	30.7°
35°	35.0°
40°	39.1°